

ILLUSION/ILLUSION TREND/ILLUSION FULL GRAIN

Tested cleaning products

- Always follow the prescribed maximum concentration of the cleaner or disinfection. If maximum concentration is below 100 %, fill up and mix with water.
- Always rinse with water and neutral soap immediately after cleaning.
To retain a long life product, it is better to rinse with water after use, even when using cleaning agents marked with a *.
- Using cleaning agents can cause discolouration, there is no deterioration of the coating layer.
- Products marked with a "V" are listed on the VAH list of disinfectants.

TYPE	CLEANER	MAXIMUM CONCENTRATION
Aliphatic hydrocarbons	RUCK® Kunststoffreiniger	100 %
Ammonia	Volvone	40 %
Surfactants	Reocid	5 %
	Universal wipes	100 % Wipes
Other	Topmaxx 421	5 %

TYPE	SKIN DISINFECTION	MAXIMUM CONCENTRATION
Alcohol	Kodan® Tinktur Forte farblos	100 % Spray
Chlorine	Hansaplast Wondspray	100 %
	Octenisept®	100 % Spray
Other	Hibicet	100 %

TYPE	SURFACE DISINFECTION	MAXIMUM CONCENTRATION
Alcohol	B 40 ^V	100 %
	Bacillol® 30 Foam ^V	100 % Foam
	Bacillol® 30 Tissues ^V	100 % Wipes
	Dax Ytdesinfektion plus	100 %
	Ethanol 100 % *	75% - no need to rinse with water after cleaning
	Isopropanol 100 % *	45% - no need to rinse with water after cleaning
	Meliseptol® ^V	100 %
	Mikrozid® AF liquid ^V	100 %
	Mikrozid® AF wipes ^V	100 % Wipes
	Mikrozid® universal wipes premium ^V	100 % Wipes
	RUCK® Flächendesinfektionstücher alkoholisch ^V	100 % Wipes
	RUCK® Sprühdesinfektion ^V	100 %
	Sagrotan® Hygiene-spray	100 % Spray
SPRINT 200	2 %	

TYPE	SURFACE DISINFECTION	MAXIMUM CONCENTRATION
Anti Covid-19	Laquick Pro	100 %
	Neutral soap water + Chlorine product *	0,1 % (1 000 ppm) active Chlorine - no need to rinse with water after cleaning
	Neutral soap water + Ethanol *	75 % Ethanol - no need to rinse with water after cleaning
	Neutral soap water + Hydrogen peroxide *	6 % Hydrogen peroxide - no need to rinse with water after cleaning
Chlorine	Actichlor Plus	0,5 % (5 000 ppm)
	Chlor-Clean Tablets	0,5 % (5 000 ppm)
	Gerमतol	5 %
	Haz-Tabs	0,5 % (5 000 ppm)
	Sodiumhypochlorite	0,5 % (5 000 ppm)
Hydrogen peroxide	Hydrogen peroxide *	6 % - no need to rinse with water after cleaning
	Incidin® OxyFoam [∨]	100 % Foam
	Incidin® OxyFoam S [∨]	100 % Foam
	Incidin® OxyWipe S [∨]	100 % Wipes
Oxygen	Dismozon pur [∨]	6 %
	Virkon Tablets	1 %
Peracetic acid	Clinell Sporidical wipes	100 % Wipes
	Ultrasol® active [∨]	5 %
Quaternary	Biguanid Fläche N [∨]	4 %
	Incidin Extra N	5 %
	Incidin Foam [∨]	100 % Foam
	RUCK® Flächendesinfektionstücher, alkoholfrei [∨]	100 % Wipes
	RUCK® Schaumdesinfektion [∨]	100 % Spray
	Suma Bac D 10	1 %
	Surfa'Safe Premium [∨]	100 % Foam
	SURFANIOS Premium	3 %
Quaternary	Terralin® protect [∨]	4 %
	Umonium medical spray	100 % Spray
Quaternary & Alcohol	B 30 [∨]	100 %
	B 45 [∨]	100 %
Other	Dettol	5 %
	Formaldehyde	30 %
	Incidin® Plus [∨]	4 %
	P3-topax® 66	5 %
	Sanit P20	100 %
	Spring	100 %
	Triamin Disinfection	100 % Wipes

2023-04-28